



NÁVOD NA MONTÁŽ:

Kód: L0017(A,I,C)

■ 1. Demontujte zadný nárazník. Konzoly nárazníka demontujte, už nebudú potrebné. Pryžové tesnenia navlečte na konzoly A a B. Demontujte vlečné oká, už sa nepoužijú. ■ 2. Uvoľnite čalúnenie z podlahy v batožinovom priestore vozidla. ■ 3. Konzoly A a B upevnite skrutkami M14x1,5x70. Na konzoly namontujte nárazník. Vyvŕtajte otvory pre skrutky M12x120 podľa obrázka. ■ 4. Spájacie zariadenie montujte po častiach podľa obrázka. Zľahka priskrutkujte rám D a konzoly C. Spájacie zariadenie vzhľadom na voľné uloženie ustavte do správnej polohy a všetky skrutkové spoje utiahnite momentom podľa tabuľky. ■ 5. Elektroinštaláciu zapojte podľa návodu. ■ 6. Skontrolujte správnosť pripojenia elektroinštalácie. ■ 7. Preveďte spätnú montáž demontovaných častí. ■ 8. Dotiahnite skrutkové spoje spojovacej gule (držáka spojovacej gule) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

■ 1. Remove the rear bumper. Dismount the consoles bumper, it will not be used any more. Thread the rubber gasket on bracket A and B. Disassemble the tow rings, it will not be used any more. ■ 2. Loosen the trim from the floor in the luggage compartment of the vehicle. ■ 3. Brackets A and B mounting screws M14x1,5x70. The brackets mount bumper. Drill holes for screws M12x120 shown. ■ 4. Install the tow-bar in parts as shown in the picture. Gently screw the frame D and B console. Put the tow-bar to an appropriate position with regard its clearance fit and torque the screw connections as shown in the table. ■ 5. Connect the electrical installation as described in the instructions for use. ■ 6. Make sure the electrical installation is properly connected. ■ 7. Reassemble any removed parts. ■ 8. Make sure the screws of the linkage ball (holder of the linkage ball) are tightened to the torque shown in the table.

DÔLEŽITÉ UPOZORNENIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vrtané otvory treba ošetriť antikoróznou hmotou.
- Použite len dodaný spojovací materiál v predpísanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
- Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku ťažného zariadenia.
- Na ťažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky ťahovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ťažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball dwnrtake is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spining moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka ťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardenss settings 8.8
 M6 - 9,5Nm, M8 - 23Nm, M10 - 46Nm, M10x1,25 - 49Nm, M12 - 79Nm, M12x1,25 - 87Nm, M12x1,5 - 83Nm, M14 - 125Nm, M16 - 195Nm